

# THE LIGHTERS

I have given every lighter an access number. I added letters of the alphabet to the access number to show the different variations of the basic lighter. Also, I have written a price range by the picture itself. Note that all lighters are valued in excellent condition regardless of the condition in the photograph unless otherwise noted. Charts and a more detailed description of how I arrived at those prices are in the back of the book. All lighters are regular size unless stated or illustrated differently.

## The First Models: 1932-1943

Access numbers 1-8 have square style corners producing 90 degree angles. They also have soldered cases.

Access numbers 1-6 have eight holes located on each side of the chimney. Access numbers 7-14, 27, 33A, and 33B have seven holes on each side of the insert's chimney, which Zippo started doing circa 1936. Zippo again started putting eight holes on each side of the insert's chimney beginning circa 1947, and is still doing this today.

Access numbers 1-10 have the U-shaped cam stop soldered in the inside of the lid.



U-shaped cam stop on Access numbers 1-10.